



- GB** Rod made of flat steel covered with PP with interchangeable accessories M5.
- D** Flachstahl Einziehband mit PP Ummantelung, mit austauschbaren Endstücken M5.
- F** Tirefil avec âme plate en acier, revêtement en PP avec des terminaux interchangeable M5.
- E** Guía pasacable en fleje acero recubierto de PP con punta intercambiable M5.
- I** Sonda passacavo in acciaio piatto rivestito in PP con accessori intercambiabili M5.



**WARNING!** This is a tool only for professional use. Risk of electrical shock. For your safety **DO NOT USE** in ducts with voltage cables.  
**ATTENZIONE!** Rischio di shock elettrico **NON USARE** in tubi con presenza di cavi in tensione elettrica.

Item	Length	
AR620	20 m	5/1
AR630	30 m	5/1
AR640	40 m	5/1
AR650	50 m	5/1
AR660	60 m	5/1

**GB** Accessories and spare parts

**D** Zubehör und Ersatzteile


**F** Accessoires et pièces de rechange

**E** Accesorios y piezas de repuestos

**I** Accessori e pezzi di ricambio

## 064/B

- GB** Standard Starting spinner  $\varnothing$  11 M5.
- D** Standard Federführungs Kopf mit Zugöse  $\varnothing$  11 M5.
- F** Tête standard avec oeillet  $\varnothing$  11 M5.
- E** Punta standard con ojal de tiro  $\varnothing$  11 M5.
- I** Puntale standard con asola  $\varnothing$  11 M5.



## AR697

- GB** Starting roller for AR691.
- D** Führungsrolle für AR691.
- F** Roue pour AR691.
- E** Ruedas para AR691.
- I** Ruota di scorrimento per AR691.



## AR695

- GB** Flexible starting spinner  $\varnothing$  10 M5.
- D** Flexible Federführungs Kopf  $\varnothing$  10 M5.
- F** Tête flexible  $\varnothing$  10 M5.
- E** Punta flexible  $\varnothing$  10 M5.
- I** Puntale flessibile  $\varnothing$  10 M5.



## Aspo 600

- GB** Horizontal steel reel.
- D** Liegende Stahl-haspel.
- F** Horizontal Enrouleur en acier.
- E** Contenedor horizontal de acero.
- I** Aspo avvolgitore orizzontale in acciaio.

